



**ANY JOB.
ANY SIZE.
ANY PLACE.**

55 Years of American Ingenuity

475

The **475** is an economical machine for the professional contractor or do-it-yourself rental market. Designed for low maintenance and high production, the 475 provides a large easy loading hopper while offering simple rugged performance

- Light weight machine
- User friendly electric dashboard
- Clear acrylic safety guard allows for easy inspection
- Durable powder coat finish
- Large 14 amp / 2 stage blower
- Semi pneumatic run flat treaded tires
- Built in tool holder
- Convertible fold down loading door

Backed by a manufacturer's
2-YEAR WARRANTY - Made in the U.S.A.

MATERIAL PRODUCTION RATE

MATERIAL	MACHINE w/single 2-Stage Blower *lbs/hr (kg/hr)
FIBERGLASS	700 (317)
CELLULOSE	2100 (952)

lbs/hr (kg/hr) rating with 150 ft. (45.8 m.) of 3" (7.6 cm.)
Hose at 16 ft. (4.8 m.) elevation, product brand, product density
and variable blowing conditions will affect production rate.

• POWER REQUIREMENT •

Double input, 15/15 amps each/120 volt/60 hz
International - Single input, 16 amp 230 volt/50 hz
CE/CSA/CUL/UL

• HOPPER CAPACITY •

14 cu. ft. (.39 m³)
Loading made easy with built in
convertible tray

• WEIGHT/DIMENSIONS •

355 lbs / 40.5" W x 31.5" D x 62" H
161 kg. / 103cm x 80cm x 157cm

• BLOWER/SIZE •

14 amp/2-stage (120 volt)
Blower System yields
140 CFM @ 3 1/2 PSI

• AIRLOCK •

12" x 10" diameter
(30.5 cm. x 25.4 cm. diameter)
3" (7.6 cm.) Outlet

Electric Dashboard

- LED start & stop buttons • Digital hourmeter
- Digital voltmeter • Variable blower control
- Recessed power supply



Dual Agitators
Designed for Constant Flow



Clear Acrylic Safety Guard
Allows for easy inspection

Backed by a manufacturer's
2-YEAR WARRANTY - Made in the U.S.A.

